

DOG RAMP

Hornbeam

Adjustable Wooden Dog Ramp for Beds, 7 Heights up to 26.8 Inches

Dogs up to 150 lb. It adjusts from 10 to 27 inches across seven settings, so the same ramp reaches an armchair, a sofa or a high bed.



SPECIFICATIONS


PRODUCT TYPE	Dog Ramp
HEIGHT RANGE	10.2 in to 26.8 in
HEIGHT SETTINGS	Seven
FRAME	Solid wood
DECK	Anti-slip ribbed carpet
ADJUSTMENT	Hinged A-frame with metal pin catch
WEIGHT CAPACITY	150 lb (68 kg)
FOLD	Flat for storage
ASSEMBLY	None - arrives ready to use
BEST FOR	Beds, sofas, armchairs

Dimensions are approximate. Natural materials vary slightly from piece to piece.

KEY FEATURES

- **Seven height settings.** One ramp covers an armchair, a sofa and a high bed, from 10 to 27 inches.
- **Solid wood frame.** Rated to 150 lb, with a metal pin catch holding the height.
- **No assembly.** Arrives ready to use and folds flat when it isn't needed.

Dimensions



OVERALL VIEW · NOT TO SCALE · DIMENSIONS AS LISTED

MEASUREMENTS

HEIGHT RANGE	10.2 in to 26.8 in
--------------	--------------------

VIORN	
ITEM Hornbeam · Dog Ramp	
DRAWING NO. VI-DR-67714-D1	SCALE Not to scale
UNITS in / cm	REVISION A
ISSUED 9 Oct 2026	

Ordering & details

Catalogue numbers are Viorn reference numbers. Quote the catalogue number when ordering or contacting us.

CONFIGURATIONS

CONFIGURATION	CATALOGUE NO.
Standard	VI-DR-67714-01

WHO IT FITS

Dogs up to 150 lb. It adjusts from 10 to 27 inches across seven settings, so the same ramp reaches an armchair, a sofa or a high bed.

WILL IT FIT?

Measure from the floor to the top of your mattress, sofa cushion or chair seat. Hornbeam locks anywhere between 10.2 and 26.8 inches, which covers most beds and almost every sofa. Above 26.8 inches it will not reach.

MATERIALS

Solid wood

CARE

Wipe or brush off dirt after use; let it dry fully before folding away.

WARRANTY & RETURNS

Frames and hardware: 5 years. Covers, foam, fabric and mesh: 1 year. Cover runs from delivery, for the original buyer; chewing, clawing, overloading, misuse and normal wear are not covered. Returns within 30 days of delivery, unused and in original packaging, with no restocking fee. If it arrives damaged or wrong, we pay the return shipping.

Setup & use

GETTING STARTED

1. **Set it low first.** Lock Hornbeam at its lowest setting and put it somewhere flat. Walk him over it for treats until he stops noticing it.
2. **Raise one notch at a time.** Move the pin up a single notch every day or two. Rushing to full height on day one is what makes dogs refuse a ramp for good.
3. **Set it to the bed.** Once he is confident, lock it at your bed height and walk beside him the first few nights.

BEFORE YOU START

- ☐ Height measured from the floor to the surface your dog steps onto
- ☐ Floor space for the full length of the ramp, plus room to turn at the bottom
- ☐ A non-slip surface under the foot of the ramp
- ☐ Treats for the first few sessions

PLACEMENT GUIDELINES

ANGLE

The longer the run for a given height, the gentler the slope. Older and arthritic dogs do best on the shallowest angle the space allows.

TOP EDGE

Set the top edge flush with, or just under, the surface it meets, so there is no lip to catch a paw.

TRAINING

Introduce it flat on the floor first, then raise it a little at a time over a few days.

Safety. Do not exceed the listed weight capacity. Check that the ramp is seated and stable before every use, and walk beside your dog until it is confident.

Questions about sizing or setup?

support@viorn.com · +1 (813) 773-3585

9am – 5pm Eastern, seven days. We reply within 12 hours on business days.

Returns. 30 days from delivery, no restocking fee.